



**Free**  
Instruction  
Sheet



## How to Sew Shower Curtain

A simple shower curtain can instantly change and refresh a bathroom! Coordinate window treatments, towels, and other accessories with your new shower curtain. To add more decorative interest, try using trims such as lace, eyelet, ruffling or ribbon.

### CUTTING:

1. Measure the distance from the bottom of the shower rod to the desired length. Add 10" for upper and lower hems.
2. Measure the width of the area to be covered by the curtain and add 4" for side hems. Standard shower curtain liners are 72" x 72", so the curtain should be cut 76" wide if using a standard liner.
3. Seam fabric together as needed, using French seams.

### SEWING:

1. Turn under and stitch a 3" double-fold hem on lower edge of curtain. Turn under and stitch 1" double-fold hem on each side of the curtain.
2. Press under 2" double-fold hem at upper edge of curtain. Open out fold and fuse a 2" strip of fusible interfacing along fold line. Fold again to form a double-fold hem.
3. Edgestitch upper hem in place or apply fusible web, following manufacturer's directions. (Fusing adds more stability to upper edge of curtain.)
4. Mark positions for grommets or buttonholes across upper hem, using the plastic liner as the guide for spacing holes. Position liner 1/4" down from upper edge of curtain.
5. Grommets: Fasten securely with pliers, using a hard surface for pounding.  
Buttonholes: Make vertical buttonholes, 1/4" to 1/2" long. To prevent buttonholes from unraveling, apply Fray Check to cut edges.
6. Insert rings or hooks.